



Model: SPT-LZR Laser for Sports Light

IMPORTANT: READ BEFORE REMOVING FIXTURE FROM CARTON. RETAIN FOR FUTURE REFERENCE

SAFETY: This fixture must be wired in accordance with the NATIONAL ELECTRICAL CODE and applicable local codes and ordinances. A person familiar with the construction and operation of the product and the hazards involved must install this product. A qualified licensed electrician should complete all work. Proper grounding is required for safety.

WARNING: Make certain power is OFF before installing or maintaining fixture.

RISK OF INJURY: Fixture may become damaged and/or unstable if not installed properly.

1. Use the Allen key to loosen the first bolt on the laser and then install the laser bracket. (figure 1)
2. Install the laser on top of the fixture in between the fins. (figure 2)
3. Adjust the angle of the fixture and then turn on the laser with the press button on the back of the laser. (figure 3)
4. Once desired position has been reached tighten the fixture's mounting bracket bolts and then remove the laser.

Fig. 1



Fig. 2



Fig. 3



Atlas Lighting Products provides a limited warranty for all products. A full warranty can be found at www.atlasled.com.

For information regarding replacement parts please e-mail:

custsvc@alpinc.com